

**DAIKIN**



# INSTALLATION MANUAL

## Condenserless water-cooled water chillers



EWLP012KBW1N  
EWLP020KBW1N  
EWLP026KBW1N  
EWLP030KBW1N  
EWLP040KBW1N  
EWLP055KBW1N  
EWLP065KBW1N



CONTENTS

	Page
Introduction.....	1
Technical specifications .....	1
Electrical specifications.....	1
Options and features.....	1
Operation range.....	2
Main components .....	2
Selection of location .....	2
Inspecting and handling the unit.....	2
Unpacking and placing the unit .....	2
Important information regarding the refrigerant used .....	2
Selection of piping material .....	3
Connecting the refrigerant circuit.....	3
Precautions when handling piping .....	3
Connecting the refrigerant circuit.....	3
Leak test and vacuum drying .....	4
Open the discharge- and liquid stop valves .....	4
Charging the unit.....	4
Checking the water circuit .....	5
Water quality specifications .....	5
Connecting the water circuit .....	5
Water charge, flow and quality .....	6
Water piping insulation .....	6
Refrigerant piping insulation .....	6
Installation of the condenser inlet temperature sensor.....	6
Connecting sensors and power supply .....	6
Field wiring .....	6
Parts table.....	6
Power circuit and cable requirements .....	6
Connection of the water-cooled water chiller power supply .....	6
Point for attention regarding quality of the public electric power supply.....	7
Interconnection cables .....	7
Before starting .....	7
How to continue.....	7

Thank you for purchasing this Daikin air conditioner.



READ THIS MANUAL ATTENTIVELY BEFORE STARTING UP THE UNIT. DO NOT THROW IT AWAY. KEEP IT IN YOUR FILES FOR FUTURE REFERENCE.

IMPROPER INSTALLATION OR ATTACHMENT OF EQUIPMENT OR ACCESSORIES COULD RESULT IN ELECTRIC SHOCK, SHORT-CIRCUIT, LEAKS, FIRE OR OTHER DAMAGE TO THE EQUIPMENT. BE SURE ONLY TO USE ACCESSORIES, OPTIONAL EQUIPMENT AND SPARE PARTS MADE BY DAIKIN WHICH ARE SPECIFICALLY DESIGNED FOR USE WITH THE EQUIPMENT AND HAVE THEM INSTALLED BY A PROFESSIONAL.

IF UNSURE OF INSTALLATION PROCEDURES OR USE, ALWAYS CONTACT YOUR DAIKIN DEALER FOR ADVICE AND INFORMATION.

The English text is the original instruction. Other languages are translations of the original instructions.

INTRODUCTION

The unit is supplied and shipped with a holding charge of 0.5 bar nitrogen (N<sub>2</sub>). This unit has to be charged with R407C refrigerant.

Pay attention to the selection of your remote condenser. Make sure to select a remote condenser developed for use with R407C.

The EWLP units can be combined with Daikin fan coil units or air handling units for air conditioning purposes. They can also be used for supplying chilled water for process cooling.

The present installation manual describes the procedures for unpacking, installing and connecting the EWLP units.

This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.

Sound pressure level is less than 70 dB(A).

Technical specifications<sup>(1)</sup>

Model EWLP		012	020	026	030
Dimensions HxWxD	(mm)		600x600x600		
Machine weight	(kg)	104	138	144	149
Connections					
• chilled water inlet and outlet	(mm)	G 1			
• condenser discharge connection (copper)	(mm)	12.7 flare	19.1 flare	19.1 flare	19.1 flare
• condenser liquid connection (copper)	(mm)	9.52 flare	12.7 flare	12.7 flare	12.7 flare

Model EWLP		040	055	065
Dimensions HxWxD	(mm)		600x600x1200	
Machine weight	(kg)	252	265	274
Connections				
• chilled water inlet and outlet	(mm)	G 1-1/2		
• condenser discharge connection (copper)	(mm)	2x 19.1 flare	2x 19.1 flare	2x 19.1 flare
• condenser liquid connection (copper)	(mm)	2x 12.7 flare	2x 12.7 flare	2x 12.7 flare

Electrical specifications<sup>(1)</sup>

Model EWLP		012-065
Power circuit		
• Phase		3N~
• Frequency	(Hz)	50
• Voltage	(V)	400
• Voltage tolerance	(%)	±10

Options and features<sup>(1)</sup>

Options

- Glycol application for chilled water temperature down to -10°C or -5°C.
- BMS-connection MODBUS (optional kit address card EKAC10C)<sup>(2)</sup>
- Remote user interface (optional kit EKRUMCA). (Necessary to additionally install kit address card EKAC10C.)<sup>(2)</sup>
- Low noise operation kit (field installation)


(1) Refer to the operation manual or engineering data book for the complete list of specifications, options and features.

(2) When EKAC10C is used in combination with remote user controller EKRUMCA then it is not possible to use the BMS-connection MODBUS.

## Features

- Voltage free contacts
  - general operation
  - alarm
  - operation compressor 1
  - operation compressor 2
- Changeable remote inputs  
Following functions can be assigned to a total of 2 digital inputs.
  - remote start/stop
  - remote cooling/heating
  - dual setpoint

## OPERATION RANGE



- CT Condensing temperature (bubble)  
 LWE Leaving water temperature evaporator  
 a Glycol  
 b Water  
 [ ] Standard operation range

## MAIN COMPONENTS (refer to the outlook diagram supplied with the unit)

- 1 Compressor
- 2 Evaporator
- 3 Accumulator
- 4 Switchbox
- 5 Chilled water in
- 6 Chilled water out
- 7 Discharge stop valve
- 8 Liquid stop valve
- 9 Evaporator entering water temperature sensor
- 10 Freeze-up sensor
- 11 Digital display controller
- 12 Power supply intake
- 13 Ball valve (field installed)
- 14 Water filter (field installed)
- 15 Air purge valve (field installed)
- 16 T-joint for air purge (field installed)
- 17 Flowswitch (with T-joint) (field installed)
- 18 Main switch

## SELECTION OF LOCATION

The units are designed for indoor installation and should be installed in a location that meets the following requirements:

- 1 The foundation is strong enough to support the weight of the unit and the floor is flat to prevent vibration and noise generation.
- 2 The space around the unit is adequate for servicing.
- 3 There is no danger of fire due to leakage of inflammable gas.
- 4 Select the location of the unit in such a way that the sound generated by the unit does not disturb anyone.
- 5 Ensure that water cannot cause any damage to the location in case it drips out of the unit.

The equipment is not intended for use in a potentially explosive atmosphere.

## INSPECTING AND HANDLING THE UNIT

At delivery, the unit should be checked and any damage should be reported immediately to the carrier claims agent.

## UNPACKING AND PLACING THE UNIT

- 1 Cut the straps and remove the cardboard box from the unit.
- 2 Cut the straps and remove the cardboard boxes with waterpiping from the pallet.
- 3 Remove the four screws fixing the unit to the pallet.
- 4 Level the unit in both directions.
- 5 Use four anchor bolts with M8 thread to fix the unit in concrete.
- 6 Remove the service front plate.

## IMPORTANT INFORMATION REGARDING THE REFRIGERANT USED

This product is factory charged with N2.

The refrigerant system will be charged with fluorinated greenhouse gases covered by the Kyoto Protocol. Do not vent gases into the atmosphere.

Refrigerant type: R407C  
 GWP<sup>(1)</sup> value: 1652.5


<sup>(1)</sup> GWP = global warming potential

Please fill in with indelible ink,

- the total refrigerant charge

on the fluorinated greenhouse gases label supplied with the product.

The filled out label must be adhered on the inside of the product and in the proximity of the product charging port (e.g. on the inside of the service cover).



- 1 total refrigerant charge
- 2 Contains fluorinated greenhouse gases covered by the Kyoto Protocol

## SELECTION OF PIPING MATERIAL

- Foreign materials inside pipes (including oils for fabrication) must be 30 mg/10 m or less.
- Use the following material specification for refrigerant piping:
  - construction material: Phosphoric acid deoxidized seamless copper for refrigerant.
  - size: Determine the proper size referring to "Technical specifications" on page 1.
  - the pipe thickness of the refrigerant piping must comply with relevant local and national regulations. For R407C the design pressure is 3.3 MPa.
- In case the required pipe sizes (inch sizes) are not available, it is also allowed to use other diameters (mm sizes), taken the following into account:
  - select the pipe size nearest to the required size.
  - use the suitable adapters for the change-over from inch to mm pipes (field supply).



For the RLK regulation the flare nuts on the stopvalves have to be replaced by flare solder connections.

## CONNECTING THE REFRIGERANT CIRCUIT



The units are equipped with a refrigerant outlet (discharge side) and a refrigerant inlet (liquid side) for the connection to a remote condenser. This circuit must be provided by a licensed technician and must comply with all relevant European and national regulations.

### Precautions when handling piping

If air, moisture or dust gets in the refrigerant circuit, problems may occur. Therefore, always take into account the following when connecting the refrigerant piping:


- Use clean and dry pipes only.
- Hold the pipe end downwards when removing burrs.
- Cover the pipe end when inserting it through a wall so that no dust and dirt enter.



When a condenserless unit is installed below the condensing unit, the following can occur:

- when the unit stops, oil will return to the discharge side of the compressor. When starting the unit, this can cause liquid (oil) hammer.
- The oil circulation will decrease


To solve these phenomena, provide oil traps in the discharge pipe every 10m if the level difference is more than 10 m.



### Connecting the refrigerant circuit

- Use a pipe cutter and flare suitable for R407C.
- Installation tools:
  - Make sure to use installation tools (gauge manifold charge hose, etc.) that are exclusively used for R407C installations to withstand the pressure and to prevent foreign materials (e.g. mineral oils such as SUNISO and moisture) from mixing into the system.
  - Vacuum pump (use a 2-stage vacuum pump with a non-return valve):
    - Make sure the pump oil does not flow oppositely into the system while the pump is not working.
    - Use a vacuum pump which can evacuate to  $-100.7$  kPa (5 Torr,  $-755$  mm Hg).
- Be sure to use both a spanner and torque wrench together when connecting or disconnecting pipes to/from the unit.


- Torque wrench
- Spanner
- Piping union
- Flare nut



- Refer to the table below for the dimensions of flare nut spaces and the appropriate tightening torque. (Overtightening may damage the flare and cause leaks.)

Pipe gauge	Tightening torque	Flare dimension A (mm)	Flare shape
Ø9.5	33~39 N•m	12.0~12.4	
Ø12.7	50~60 N•m	15.4~15.8	
Ø19.1	97~110 N•m	22.9~23.3	


- When connecting the flare nut, coat the flare inner surface with ether oil or ester oil and initially tighten 3 or 4 turns by hand before tightening firmly.



- Check the pipe connector for gas leaks.



When inserting the refrigerant piping in the wall hole, take care not to let dust or moisture come into the piping. Protect the pipes with a cap or seal the pipe end completely with tape.



- The discharge and liquid line are to be connected with flare connections to the remote condenser piping. For use of the correct pipe diameter see "Technical specifications" on page 1.

- piping length: equivalent = 50 m  
maximum height = 30 m



Make sure the pipes are filled with N<sub>2</sub> during welding in order to protect the pipes against soot.

There should be no blockage (stopvalve, solenoid valve) between the remote condenser and the provided liquid injection of the compressor.

## Leak test and vacuum drying

The units were checked for leaks by the manufacturer.

After connection of the piping, a leak test must be performed and the air in the refrigerant piping must be evacuated to a value of 4 mbars absolute by means of a vacuum pump.


## Open the discharge- and liquid stop valves.

### 1 to open

- Remove the cap (1) and turn the shaft (2) counterclockwise with hexagon socket screw keys (3) (JIS B 4648 nominal size 4 mm).
- Turn it all the way until the shaft stops.
- Tighten the cap firmly.

### 2 to close

- Remove the cap and turn the shaft clockwise.
- Tighten the shaft firmly until it reaches the sealed area (4) of the body.
- Tighten the cap firmly.



#### NOTE



- Use a charging hose with push rod when using the service port (5).
- Check for refrigerant gas leakage after tightening the cap.
- Make sure to keep stop valve open during operation.



Do not purge the air with refrigerants. Use a vacuum pump to vacuum the installation.

## Charging the unit

First perform a rough refrigerant charge according to the table:

	refrigerant charge (kg)
EWLP012	0.9+(0.06xLLP)+(VRCx0.38)
EWLP020	1.5+(0.12xLLP)+(VRCx0.38)
EWLP026	1.7+(0.12xLLP)+(VRCx0.38)
EWLP030	2.0+(0.12xLLP)+(VRCx0.38)
EWLP040	2x[1.5+(0.12xLLP)+(VRCx0.38)]
EWLP055	2x[1.7+(0.12xLLP)+(VRCx0.38)]
EWLP065	2x[2.0+(0.12xLLP)+(VRCx0.38)]

VRC = volume of remote condenser (l)  
LLP = length of liquid pipe (m)

### Next perform a fine-tuning

For fine-tuning of the refrigerant charge, the compressor must operate.

- If the liquid-line sightglass is showing seal after the rough charging (due to possible different conditions), add 10% refrigerant charge weight.
- If the liquid-line sightglass is showing some gas-bubbles, the rough refrigerant charge is sufficient by fine-tuning the additional 10% refrigerant charge weight.
- If the liquid-line sightglass is showing flash gas, then charge until one of the previous situations occur. Then fine-tune with the additional 10% refrigerant charge weight. The unit must have the time to stabilize which means that this charging has to be done in a smooth way.

#### NOTE



Take care for contamination of the remote condenser in order to avoid blocking of the system. It is impossible for Daikin to control the contamination of the "foreign" condenser of the installer. The Daikin unit has a strict contamination level.



Use the liquid line check valve for charging refrigerant and make sure to charge liquid.

## CHECKING THE WATER CIRCUIT

The units are equipped with a water inlet and water outlet for connection to a chilled water circuit. This circuit must be provided by a licensed technician and must comply with all relevant European and national regulations.



The unit is only to be used in a closed water system. Application in an open water circuit can lead to excessive corrosion of the water piping.


Before continuing the installation of the unit, check the following points:

### ■ Additional components not delivered with the unit

- 1 A circulation pump must be provided in such a way that it discharges the water directly into the heat exchanger.
- 2 Drain taps must be provided at all low points of the system to permit complete drainage of the circuit during maintenance or in case of shut down.
- 3 Vibration eliminators in all water piping connected to the chiller are recommended to avoid straining the piping and transmitting vibration and noise.

### ■ Additional water piping delivered with the unit


All additional water piping must be installed on the system according to the piping diagram as mentioned in the operation manual. The flowswitch must be connected as described on the wiring diagram. See also chapter "Before starting" on page 7.



2x Ball valve




1x Water filter




1x Air purge



1x T-joint for air purge



2x Flowswitch pipe




1x Flowswitch  
+  
1x T-joint

- 4 A flowswitch must be installed in the water outlet pipe of the evaporator to prevent the unit from operating at a water flow which is too low.



It is very important to install the flowswitch as shown in the figure. Observe the position of the flowswitch in relation to the direction of the water flow. If the flowswitch is mounted in an other position, the unit is not protected properly against freezing.



A terminal (X65A) is provided in the switch box for the electrical connection of the flowswitch (S10L).

- 5 Shut-off valves must be installed at the unit so that normal servicing of the water filter can be accomplished without draining the complete system.

- 6 Air purge valves must be provided at all high points of the system. The vents should be located at points which are easily accessible for servicing.

- 7 The water filter must be installed in front of the unit for removing dirt from the water to prevent damage to the unit or blockage of the evaporator. The water filter must be cleaned on a regular base.

## WATER QUALITY SPECIFICATIONS

		evaporator water		tendency if out of criteria
		circulating water [<20°C]	supply water	
<b>Items to be controlled</b>				
pH	at 25°C	6.8-8.0	6.8-8.0	A + B
Electrical conductivity	[mS/m] at 25°C	<40	<30	A + B
Chloride ion	[mg Cl <sup>-</sup> /l]	<50	<50	A
Sulfate ion	[mg SO <sub>4</sub> <sup>2-</sup> /l]	<50	<50	A
M-alkalinity (pH 4.8)	[mg CaCO <sub>3</sub> /l]	<50	<50	B
Total hardness	[mg CaCO <sub>3</sub> /l]	<70	<70	B
Calcium hardness	[mg CaCO <sub>3</sub> /l]	<50	<50	B
Silica ion	[mg SiO <sub>2</sub> /l]	<30	<30	B
<b>Items to be referred to</b>				
Iron	[mg Fe/l]	<1.0	<0.3	A + B
Copper	[mg Cu/l]	<1.0	<0.1	A
Sulfide ion	[mg S <sup>2-</sup> /l]	not detectable		A
Ammonium ion	[mg NH <sub>4</sub> <sup>+</sup> /l]	<1.0	<0.1	A
Remaining chloride	[mg Cl/l]	<0.3	<0.3	A
Free carbide	[mg CO <sub>2</sub> /l]	<4.0	<4.0	A
Stability index		—	—	A + B

A = corrosion B = scale

## CONNECTING THE WATER CIRCUIT

The evaporator is provided with GAS female pipe thread connections for the water inlet and outlet (refer to the outlook diagram). Evaporator water connections are to be made in accordance with the outlook diagram, respecting the water in- and outlet.

If air, moisture or dust gets in the water circuit, problems may occur. Therefore, always take into account the following when connecting the water circuit:

1. Use clean pipes only.
2. Hold the pipe end downwards when removing burrs.
3. Cover the pipe end when inserting it through a wall so that no dust and dirt enter.




- Use a good thread sealant for the sealing of the connections. The sealing must be able to withstand the pressures and temperatures of the system, it must also be resistant to the used glycol in the water.
- The exterior of the water pipes must be adequately protected against corrosion.

## WATER CHARGE, FLOW AND QUALITY

To assure proper operation of the unit a minimum water volume is required in the system and the water flow through the evaporator must be within the operation range as specified in the table below.

	Minimum water volume (l)	Minimum water flow	Maximum water flow
EWLP012	62.1	31 l/min	69 l/min
EWLP020	103	53 l/min	115 l/min
EWLP026	134	65 l/min	153 l/min
EWLP030	155	76 l/min	179 l/min
EWLP040	205	101 l/min	229 l/min
EWLP055	268	131 l/min	307 l/min
EWLP065	311	152 l/min	359 l/min

 The water pressure should not exceed the maximum working pressure of 10 bar.

**NOTE** Provide adequate safeguards in the water circuit to make sure that the water pressure will never exceed the maximum allowable working pressure.

## WATER PIPING INSULATION

The complete water circuit, inclusive all piping, must be insulated to prevent condensation and reduction of the cooling capacity.

Protect the water piping against water freezing during winter period (e.g. by using a glycol solution or heatertape).

## REFRIGERANT PIPING INSULATION

To prevent burning injuries by accidental touching the hot (max 135°C) discharge pipe, it must be insulated thoroughly.


A minimum of insulation to protect the liquid pipe from damage is advisable.

## INSTALLATION OF THE CONDENSER INLET TEMPERATURE SENSOR

For condenser water inlet control it is possible to enlarge the provided water sensor cable for a total length of 100 m. It gives the opportunity to place the water sensor near to the remote watercooled condenser in order to have a reliable condenser water inlet measurement.


### Connecting sensors and power supply

Sensors can be located up to 100 meters distance away from the controller provided that you use cables with  $\text{Ø}1 \text{ mm}^2$  min. To improve immunity against noises we recommend using shielded cables (connect just one end of the shielding to the earth of the electrical panel).



- 1 Switch box (with connector X62A on I/O PCB)
- 2 Sensor cable (length  $\pm 1$  m)
- 3 Sensor
- 4 Remote watercooled condenser
- 5 Cable
- 6 Interconnection (IP67)

## FIELD WIRING

 All field wiring and components must be installed by a licensed electrician and must comply with relevant European and national regulations.

The field wiring must be carried out in accordance with the wiring diagram supplied with the unit and the instructions given below.


Be sure to use a dedicated power circuit. Never use a power supply shared by another appliance.

### Parts table

F1,2,3	.....Main fuses for the unit
H3P	.....Indication lamp alarm
H4P,H5P	.....Indication lamp operation compressor circuit 1, circuit 2
K1F,K2F	.....fancontactor
PE	.....Main earth terminal
S7S	.....Switch for remote cooling/heating change-over valve or dual setpoint
S9S	.....Switch for remote start/stop or dual setpoint
- - -	.....Field wiring

### Power circuit and cable requirements

- 1 The electrical power supply to the unit must be arranged so that it can be switched on or off independently of the electrical supply to other items of the plant and equipment in general.
- 2 A power circuit must be provided for connection of the unit. This circuit must be protected with the required safety devices, i.e. a circuit breaker, a slow blow fuse on each phase and an earth leak detector. Recommended fuses are mentioned on the wiring diagram supplied with the unit.

 Switch off the main isolator switch before making any connections (switch off the circuit breaker, remove or switch off the fuses).

### Connection of the water-cooled water chiller power supply

- 1 Using the appropriate cable, connect the power circuit to the N, L1, L2 and L3 terminals of the unit. (cable section 2.5-10 mm<sup>2</sup>)
- 2 Connect the earth conductor (yellow/green) to the earthing terminal PE.



## Point for attention regarding quality of the public electric power supply

- This equipment complies with EN/IEC 61000-3-11<sup>(1)</sup> provided that the system impedance  $Z_{sys}$  is less than or equal to  $Z_{max}$  at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a system impedance  $Z_{sys}$  less than or equal to  $Z_{max}$ .

	$Z_{max}$ (Ω)
EWLP012	0.28
EWLP020	0.23
EWLP026	0.22
EWLP030	0.21
EWLP040	0.22
EWLP055	0.21
EWLP065	0.20

- Only for EWLP026~065: Equipment complying with EN/IEC 61000-3-12<sup>(2)</sup>

## Interconnection cables

- Voltage free contacts  
The PCB is provided with some voltage free contacts to indicate the status of the unit.  
The PCB is also provided with a voltage free contact for the operation of fans.  
When the compressor is running, the contact is closed and a fan contact can be activated.  
These voltage free contacts can be wired as described on the wiring diagram.
- Remote inputs  
Besides the voltage free contacts, there are also possibilities to install remote inputs.  
They can be installed as shown on the wiring diagram.

## BEFORE STARTING



The unit should not be started, not even for a very short period of time, before the following pre-commissioning checklist is filled out completely.

tick ✓ when checked	standard steps to go through before starting the unit
<input type="checkbox"/> 1	Check for <b>external damage</b> .
<input type="checkbox"/> 2	Install <b>main fuses, earth leak detector</b> and <b>main switch</b> . Recommended fuses: aM according to IEC standard 269-2. <i>Refer to the wiring diagram for size.</i>
<input type="checkbox"/> 3	Supply the main voltage and check if it is within the allowable $\pm 10\%$ limits of the nameplate rating. The electrical <b>main power supply</b> must be arranged so, that it can be switched on or off independently of the electrical supply to other items of the plant and equipment in general. <i>Refer to the wiring diagram, terminals N, L1, L2 and L3.</i>
<input type="checkbox"/> 4	Supply water to the evaporator and verify if <b>waterflow</b> is within the limits as given in the table under " <b>Water charge, flow and quality</b> " on page 6.
<input type="checkbox"/> 5	The piping must be completely <b>purged</b> . See also chapter " <b>Checking the water circuit</b> " on page 5.
<input type="checkbox"/> 6	Connect the <b>flowswitch</b> and <b>pumpcontact</b> , so that the unit can only come in operation when the waterpumps are running and the waterflow is sufficient. Make sure a water filter is installed before the water inlet of the unit.
<input type="checkbox"/> 7	Connect the optional field wiring for <b>pumps start-stop</b> .
<input type="checkbox"/> 8	Connect the optional field wiring for <b>remote control</b> .

### NOTE



- Try to reduce the drilling in the unit to a minimum. If drilling is imprevntable, remove the iron filling thoroughly in order to prevent surface rust!
- It is necessary to read the operation manual delivered with the unit before operating the unit. It will contribute to understand the operation of the unit and its electronic controller.
- Verify on the wiring diagram all electrical actions mentioned above, in order to understand the operation of the unit more deeply.
- Close all switch box doors after installation of the unit.

I do confirm having executed and checked all the above mentioned items.

Date

Signature

Keep for future reference.



## HOW TO CONTINUE

After installation and connection of the packaged water-cooled water chiller, the complete system must be checked and tested as described in "Checks before initial start-up" in the operation manual supplied with the unit.

Fill out the brief operation instructions form and fix it visibly near the operating site of the refrigeration system.

(1) European/International Technical Standard setting the limits for voltage changes, voltage fluctuations and flicker in public low-voltage supply systems for equipment with rated current  $\leq 75$  A.

(2) European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input current  $> 16$  A and  $\leq 75$  A per phase.



# BRIEF OPERATION INSTRUCTIONS

## EWLP-KB Condenserless water-cooled water chiller

Equipment supplier : .....

Service department : .....

.....

.....

.....

.....

Phone : .....

Phone : .....

### EQUIPMENT TECHNICAL DATA

Manufacturer	: DAIKIN EUROPE .....	Power supply (V/Ph/Hz/A)	: .....
Model	: .....	Maximum high pressure	: .....30.9 bar
Serial Number	: .....	Charging weight (kg) R407C	: .....
Year of construction	: .....		

### START-UP AND SHUT DOWN

- ▶ Start-up by switching on the circuit breaker of the power circuit. The operation of the water chiller is then controlled by the Digital Display Controller.
- ▶ Shut-down by switching off the controller and the circuit breaker of the power circuit.



#### WARNINGS

**Emergency shut down** : Switch off the **circuit breaker** located on .....

.....

.....

**Air inlet and outlet** : Always keep the air inlet and outlet free to obtain the maximum cooling capacity and to prevent damage to the installation.

**Refrigerant charge** : Use refrigerant R407C only.

**First aid** : In case of injuries or accidents immediately inform:



▶ **Company management** : **Phone** .....

▶ **Emergency physician** : **Phone** .....

▶ **Fire service** : **Phone** .....





\*4PW61665-1 A 0000000Q\*

Copyright 2010 Daikin

**DAIKIN EUROPE N.V.**

Zandvoordestraat 300, B-8400 Oostende, Belgium

4PW61665-1A 2012.04